

### MOUNTING LOCATION:

Upper right side of dash

### TOOLS REQUIRED:

Phillips screwdriver

### HARDWARE INCLUDED:

None

### CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: **75144-100**

MFG: **WESTERN STAR**

MODELS & YEARS:

**SEMI - ALL 1996-2014**

### \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

NOTE: Mounts taken off of older model trucks may need to enlarge the screw hole in mount to fit newer models.

- STEP #1 Remove (2) Phillips screws located on top of the right instrument panel located above the dashboard rocker switches.
- STEP #2 Pull woodgrain panel back approximately 2 inches on top. Panel is hinged on the bottom. Locate air vent at upper right-hand corner of panel.
- STEP #3 Slide InDash mount into right corner position and align outside hole of woodgrain panel hole and reassemble factory Phillips screw through panel and InDash Mount into threaded nut of dash.
- STEP #4 Attach phone holder to Mount.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Final install showing location



02-20-13